



DTC P033629, P261937, P034A30, P261738, P261836, P034A31, P033531

1. DTC Description



DTC	Description	Faulty Area
P033629	DFC for Crankshaft Signal Diagnose - Disturbed Signal	<ul style="list-style-type: none"> • ECU • Wiring harness and connector • Crankshaft speed sensor
P261937	CrS Signal Frequency Higher than Threshold	
P034A30	At the Expected Position the Gap was not Detected Again	
P261738	Dynamic Timeout of Two Consecutive Tooth Periods	
P261836	CrS Signal Below Speed Threshold	
P034A31	No Gap could be Detected in the Signal	
P033531	DFC for Crankshaft Signal Diagnose - No Signal	

2. Diagnosis Procedure

Test Conditions	Details/Results/Actions
1. General inspection	<p>A. Inspect ECU wiring harness connector E24 for looseness, aging and poor contact, etc.</p> <p>B. Inspect crankshaft speed sensor wiring harness connector E04 for looseness, aging and poor contact, etc.</p> <p>Is it normal?</p> <p>Yes</p> <p>Go to step 2.</p> <p>No</p> <p>Repair the faulty area.</p>

Test Conditions	Details/Results/Actions
<p data-bbox="172 232 727 264">2. Inspect wiring harness for open circuit</p> <div data-bbox="177 293 820 898">  <p data-bbox="188 860 293 884">G3112148</p> </div>	<p data-bbox="847 282 1497 584"> A. Turn the ignition switch to "LOCK" position. B. Disconnect the ECU wiring harness connector E24. C. Disconnect the crankshaft speed sensor wiring harness connector E04. D. Measure resistance between terminals 13, 14 of ECU wiring harness connector E24 and terminals 1, 2 of crankshaft speed sensor wiring harness connector E04 with a multimeter. </p> <p data-bbox="879 607 1326 633">Standard resistance: Less than 5 Ω</p> <p data-bbox="879 656 1134 683">Is resistance normal?</p> <p data-bbox="879 705 927 732">Yes</p> <p data-bbox="879 754 1034 781">Go to step 3.</p> <p data-bbox="879 804 919 831">No</p> <p data-bbox="879 853 1497 976"> Inspect circuit between terminals 13, 14 of ECU wiring harness connector E24 and terminals 1, 2 of crankshaft speed sensor wiring harness connector E04. </p>
<p data-bbox="172 994 887 1025">3. Inspect for short circuit to ground in wiring harness</p> <div data-bbox="177 1055 820 1458">  <p data-bbox="188 1435 293 1460">G3112149</p> </div>	<p data-bbox="847 1043 1497 1312"> A. Turn the ignition switch to "LOCK" position. B. Disconnect the ECU wiring harness connector E24. C. Disconnect the crankshaft speed sensor wiring harness connector E04. D. Measure resistance between terminals 1, 2 of crankshaft speed sensor wiring harness connector E04 and reliable ground with a multimeter. </p> <p data-bbox="879 1335 1337 1361">Standard resistance: 10 MΩ or more</p> <p data-bbox="879 1384 1134 1411">Is resistance normal?</p> <p data-bbox="879 1433 927 1460">Yes</p> <p data-bbox="879 1482 1034 1509">Go to step 4.</p> <p data-bbox="879 1532 919 1559">No</p> <p data-bbox="879 1581 1497 1671"> Inspect circuit between terminals 1, 2 of crankshaft speed sensor wiring harness connector E04 and reliable ground. </p>

Test Conditions	Details/Results/Actions
4. Inspect for internal short circuit in wiring harness	
	<p>A. Turn the ignition switch to "LOCK" position.</p> <p>B. Disconnect the ECU wiring harness connector E24.</p> <p>C. Disconnect the crankshaft speed sensor wiring harness connector E04.</p> <p>D. Measure resistance between terminals 1 and 2 of crankshaft speed sensor wiring harness connector E04 with a multimeter.</p> <p>Standard resistance: 10 MΩ or more</p> <p>Is resistance normal?</p> <p>Yes</p> <p>Go to step 5.</p> <p>No</p> <p>Inspect the crankshaft speed sensor wiring harness circuit.</p>
5. Inspect resistance	
	<p>A. Turn the ignition switch to "LOCK" position.</p> <p>B. Disconnect the crankshaft speed sensor wiring harness connector E04.</p> <p>C. Measure resistance between terminals 1 and 2 of crankshaft speed sensor with a multimeter.</p> <p>Standard resistance: 850 ~ 950 Ω at 20°C</p> <p>Is resistance normal?</p> <p>Yes</p> <p>Go to step 6.</p> <p>No</p> <p>Replace the crankshaft speed sensor.</p>

Test Conditions	Details/Results/Actions
<p>6. Inspect engine control module power supply circuit</p>  <p>G3112014</p>	<p>A. Turn the ignition switch to "LOCK" position.</p> <p>B. Measure from back side of ECU wiring harness connector C05.</p> <p>C. Turn ignition switch to "ON", and measure voltage between terminals 1, 3 and 5 and reliable ground.</p> <p>Standard voltage: 11 ~ 14 V</p> <p>Is measurement normal?</p> <p>Yes</p> <p>Go to step 7.</p> <p>No</p> <p>Inspect and repair ECU power supply circuit.</p>
<p>7. Inspect engine control module ground circuit</p>  <p>G3112015</p>	<p>A. Turn the ignition switch to "LOCK" position.</p> <p>B. Measure from back side of ECU wiring harness connector C05.</p> <p>C. Measure resistance between terminals 2, 4 and 6 of ECU wiring harness connector C05 and reliable ground with a multimeter.</p> <p>Standard resistance: Less than 5 Ω</p> <p>Is measurement normal?</p> <p>Yes</p> <p>Replace the engine control module.</p> <p>Refer to: Engine Control Module (3.1.13 Electronic Control System, Removal and Installation).</p> <p>No</p> <p>Inspect and repair ECU ground circuit.</p>