


## Components Location



Item	Description	Item	Description
1	Steering wheel assembly	3	Steering shaft dust boot assembly
2	Steering column assembly	4	Steering gear assembly