

DTC	Possible Fault Causes	Repair Recommendation
B100678	Left Front Door Switch Fault	Inspect the door switch and circuit
B100778	Left Rear Door Switch Fault	
B100878	Right Front Door Switch Fault	
B100978	Right Rear Door Switch Fault	
B104329	Wireless Key 1 Synchronization Count Value is Abnormal	Relearn the key
B104429	Wireless Key 2 Synchronization Count Value is Abnormal	
B104749	Left Front Tire Pressure Sensor Battery Low	Replace the tire pressure sensor
B104849	Right Front Tire Pressure Sensor Battery Low	
B104949	Left Rear Tire Pressure Sensor Battery Low	
B105049	Right Rear Tire Pressure Sensor Battery Low	
B105947	Left Front Tire Pressure Too Low	The tire pressure is abnormal and inflate the tire properly
B106047	Right Front Tire Pressure Too Low	
B106147	Left Rear Tire Pressure Too Low	
B106247	Right Rear Tire Pressure Too Low	
B105944	Left Front Tire Pressure Sensor Lost	Check for the radio frequency interference, or replace the tire pressure sensor
B106044	Right Front Tire Pressure Sensor Lost	
B106144	Left Rear Tire Pressure Sensor Lost	
B106244	Right Rear Tire Pressure Sensor Lost	
B105945	Left Rear Tire Pressure Sensor Fault	Replace the tire pressure sensor
B106045	Left Rear Tire Pressure Sensor Fault	
B106145	Left Rear Tire Pressure Sensor Fault	
B106245	Left Rear Tire Pressure Sensor Fault	
B101278	Turning Switch Fault	Inspect the turning switch circuit
B100214	Short Circuit in Rear Fog Lamp	Replace the lamp
B101179	Emergency Alarm Switch Fault	Inspect the emergency alarm switch circuit
U001988	Bus off	Inspect the CAN bus
U114587	AC CAN Fault	Inspect the AC controller
U112587	EMS CAN Fault	Inspect the EMS
U113587	ESP CAN Fault	Inspect the ESP
U110387	SRS CAN Fault	Inspect the SRS
U111087	Other Network Management Node CAN Fault	Inspect other network management node
U100187	CAN Abnormal	Inspect the CAN bus connection
B106355	Tire Pressure Matching Fault	Reconfigure 4 ID